S.M.S.L



使用说明书/USER MANUAL

本说明书的内容可能会随版本更改如有变动, 恕不另行通知
The contents of this manual may be changed with the edition, and are subject to change without notice.

■ 安全注意事项

- 请将本音响系统安装在通风良好、阴凉、干燥、干净的位置,远离直射阳光热源、振动、灰尘、潮 湿或寒冷。
- 只能使用本机指定的电压。使用高于指定数值的电压很危险,而且可能导致火灾,损坏本机或 造成人身伤害。对于使用高于指定电压造成的任何损害,我司将不负任何责任。
- 不要试图自行改造或修理本机。如果需要任何服务,请与销售或者我司客服人员联系。不管有 任何理由,都没有打开机壳的必要。
- 如果打算长时间不使用本机(比如度假时),请从墙壁交流电源插座上断开电源线的连接。

重要提示:

本说明书所提到的产品规格和资讯仅供参考。如有内容更新,恕不另行诵知。

保修条款

、服务期限

佛山双木三林科技有限公司承诺产品的良好品质,产品自售出之后7天内正常使用情况下出现 故障,客户可以选择很货或者保修(不影响二次销售才可退货)。正常使用一年内出现故障可以 免费保修。

- 二、购买日期以销售商开出的购机发票或收据日期为准,网购可以交易截图为准。
- 三、有以下情况都不能享受"三包"服务
 - 1.一切人为因素损坏,包括非正常工作环境下使用或不按照说明书使用。
 - 2.用户私自拆机、改装、维修。
 - 3.使用非指定或许可的配件造成损坏的。
 - 4.机身的OC或保修贴损毁。
 - 5.不能出示有效购机凭证。
 - 6.不属于本公司产品。

四、保修方式为送修

此条款只适于中国大陆,其它地区请参考当地销售代理商的规定和国家法规。



- 使用性能优异的MM唱头放大电路,在46dB的高增益下,仍然有-81dB的失真度。
- · 具备pop声控制电路,开关机没有pop声。
- 使用低噪声电源、确保提供宁静的音乐背景。
- 极致的小体积,放置更加灵活。
- 最短信号路径,高音质设计。

技术参数

耳机输出功率	90mWx2(32壓7)
频率响应	20Hz-20kHz
THD+N(不计权)	0.008%(-81dB)
通道分离度	77dB(1kHz)
增益	46dB
信噪比	84dB
消耗功率	1W
电源输入	DC 5V 500mA
尺寸	94x30x96mm(WxHxD)
重量	0.205kg

部件介绍






- 耳机音量旋钮
- 4 开关
- RCA输出

- ☑ 6.35mm耳机接口
- 5 RCA输入
- 电源输入接口

- 3 指示灯
- 6 接地

连接方式





- Install this unit in a well ventilated, cool, dry, clean place-away from direct sunlight, heat sources, vibration, dust, moisture, or cold..
- Use the voltage specified on this unit Only. Using this unit with a higher voltage than specified is dangerous
 and may cause fire, damage to this unit, or personal injury. Our company will not be held responsible for any
 damage resulting from the use of this unit with a voltage other than that specified.
- Do not attempt to modify or fix this unit by yourself. Contact alesperson or customer service when any service is needed. The cabinet should never be opened for any reason.
- When not planning to use this unit for long periods of time (i.e. when going on vacation), disconnect the power cable from the AC wall outlet.

Important note:

The product specifications and information mentioned in this manual are for reference only. The content of this manual is subject to change without notice.

Warranty Terms

1.The Term of Service

Foshan Shuangmusanlin Technology Co., Ltd promises to offer good-quality products. If the product is broken in 7 days after purchasing when you use it normally, you can choose to send it back for return, replacement or repairing (only the product does not affect the second sales can be returned). Repairing for free in one year if you use it normally.

2.Date of purchase is in accordance with the date on invoice or receipt uesd by seller, and if you buy it on line, you can show the screenshot of trade.

3.If an inappropriate usage causes the unit damaged, the warranty will be void. As below.

- All damages by inappropriate use, including using it under non-normal working environment or without following the instructions.
- Dismantling, refitting, repairing by user in private.
- Causing damage by using some fittings instead of the designative or accredited ones.
- Cannot provide credible proof of purchase.

4. Sending it back to our company for repairing.

5.Contact your S.M.S.L Audio reseller for a return or replacement.



- Using a high-performance MM phono amplifier circuit, with a high gain of 46dB, a distortion level of -81dB is still achieved.
- With pop control circuitry, there is no popping sound when switching on and off.
- Low-noise power supply ensures a guiet sound background.
- · Extremely small size for flexible placement.
- Optimized signal path and high sound quality design.

Specifications

Headphone Output Power	90mWx2(32Ω
Frequency Response	20Hz-20kHz
THD+N(unweighted)	0.008%(-81dB)
Channel Separation	77dB(1kHz)
Gain	46dB
SNR	84dE
Power Consumption	1W
Power Input	DC 5V 500mA
Size	94x30x96mm(WxHxD)
Weight	0.205kg

SMSL reserves the right to make improvements which may result in specification or feature changes without notice.







- Headphone Volume knob
- 4 ON/OFF
- RCA Output

- 2 6.35mm headphone jack
- B RCA Input
- B Power Input Connector
- Indicator light
- 6 Ground

Connection instruction

